November, 2024

Turbo Tack™ for White Out®

Add a tacky surface to your paint booth walls

Like90 Turbo Tack for White Out is another innovative component of Like90's patented Clean Booth System. Turbo Tack is a water-based coating that adds a tacky surface to the White Out peelable dry film, capturing dust, overspray and other contamination on booth walls, keeping it out of your paintwork.

Turbo Tack will remain tacky until it is inundated with contamination. When the surface loses its tack, re-coat it with Turbo Tack. You may also apply White Out on top of Turbo Tack and then re-coat the White Out dry film after it has cured.

Turbo Tack is NOT a standalone-booth coating and should only be applied on top of the cured White Out dry film. Any excess Turbo Tack coating should be wiped from the surface while it is still wet. If Turbo Tack dries on a surface without White Out, glass cleaner will assist in removal.

Product Details

- Part numbers: 10064 - 1-gallon
- Coverage: ~ 535 sq. ft/gallon (theoretical, @ 3 mils wet)
- Color: White liquid, dries clear
- VOC: < 60g/L
- Shipping info: Not regulated for transport

Personal Protection

- **Eye/face protection:** Avoid eye contact with vapors, mists, or spray. Safety glasses with side shields will provide additional protection.
- **Skin protection:** Select and use gloves and/or protective clothing to prevent skin contact after making an exposure assessment. Gloves made from neoprene or nitrile rubber are recommended.
- **Respiratory protection:** Avoid breathing of vapors, mists or spray. Use a particulate respirator in accordance with applicable safety regulations.

Application Instructions

Spray equipment: Conventional, HVLP, Gravity Feed: air – 25 to 30 psi at gun; fluid tip 1.8 to 2.2mm.

1. Mask any surfaces that do not have Like90 White Out on them including lights, windows, door handles, etc.
2. Turn on the booth's spray cycle and set the booth temperature to 75° F (24° C).
3. Vigorously shake or stir coating in container.
4. Apply a light coat (~3 mils wet) to booth panels you wish to coat with Turbo Tack, from floor level to at least 5 or 6 feet high. Use a well-maintained HVLP gun with a 1.8 to 2.0mm spray tip.
5. Clean spray equipment immediately with warm water. Wipe excess coating from surfaces with a damp rag.

Removal

- Turbo Tack will be removed when the White Out dry film is peeled from the booth's surfaces.

IMPORTANT NOTICE TO PURCHASER: The information in this document is based on tests that we believe are reliable. Your results may vary due to differences in test types and conditions. You must evaluate and determine whether the product is suitable for your intended application. Since conditions of product use are outside of our control and vary widely, the following is made in lieu of all express and implied warranties (including the implied warranties of merchantability and fitness for a particular purpose): Except where prohibited by law, Seller's only obligation and your only remedy, is replacement or, at Seller's option, refund of the original purchase price of product that is shown to have been defective when you received it. In no case will Seller be liable for any direct, indirect, special, incidental, or consequential damages (including, without limitation, lost profits, goodwill, and business opportunity) based on breach of warranty, condition or contract, negligence, strict tort, or any other legal or equitable theory.